


Required Tools:

- (2) 9/16" Open-End wrench
- Level
- Tape measure

Supplied Parts:

- Isolator assembly with spring.



Step by Step Instructions:

1. Read the entire installation instructions before installing the VIMM isolators.
2. Place the VIMM on the building structure, steel is preferred.
3. Nut "a" can be loosened or tightened to adjust the height of the top plate "c" to allow it to be welded to the structure.
4. Weld the VIMM to the structure.
5. Once all of the VIMM isolators are attached to the structure, the unit can be placed on the VIMM isolators.
6. If required by the building code in your area, attach the unit to the Top Plate "c" by welding the unit to the top plate.
7. Once the VIMM has been loaded, the weight of the unit will be on the isolator housing. Loosen nut "a" one full turn on each isolator then tighten nut "b" a half turn.
8. Repeat Step 7 on each isolator in a clockwise direction around the unit at each isolator position as many times as needed until the Top Plate "c" is no longer resting on the housing and the top washer is loose.
9. Once Step 8 is complete, the isolators have been properly installed.